



1 RELEASE SIDE TOGGLES AND UNZIP THE COLLAPSED COOLER TO OPEN



2 FOAM PANELS FOLD UP AND VELCRO TOGETHER TO PROVIDE INSULATION AND STRUCTURE



3 PULL WATERPROOF COOLER LINER UP FOLD OVER AND VELCRO TO FOAM PANELS



4 PULL UP EXTERIOR FABRIC AND VELCRO TO FOAM PANELS



5 ENJOY!

