

Salida 2 & 4-Pitching Instructions

In order to familiarize yourself with your new tent, we recommend you "test pitch" before your first camping trip. For additional information please visit www.Kelty.com. Happy Trails!



Package Includes: Tent Body, Rain Fly, 2 poles, Guy Cords, Tent Stakes.



Salida 2 pictured



Step 1: Find an even piece of ground, lay out tent body and stake corners. Assemble poles and lay them corner to corner crossing near the center of the tent.



Step 2: Insert pole tip into grommet on one corner of each pole. From opposite corner, flex pole and insert tip into grommet.



Grommet Pole Attachment



Pole Clip



Center Pole Clips



Tent Fly Side Release Buckle Attachment



Step 3: Attach center clips to top pole at center where poles cross. Work around the tent attaching all clips to the poles.



Step 4: Drape rain fly over tent body. Be sure zipper in fly lines up with tent body door. Attach rain fly side release buckles at stake loop. Stake out tent vestibule and guy out as needed.