

# Outfitter Pro 2, 3, & 4-Pitching Instructions




Outfitter Pro 2 pictured

In order to familiarize yourself with your new tent, we recommend you "test pitch" before your first camping trip. For additional information please visit <http://www.kelty.com/c-tents-shelters.aspx>.



Package Includes: Tent Body, Rain Fly, 2 Aluminum Poles, Guy Cords (attached to rain fly), Tent Stakes, Pole and Stake Bag.



Step 1: Find an even piece of ground; be sure area is clear of debris. Assemble poles. Lay poles on tent forming an "X".



Step 2: Insert pole tip into grommet on stake loop at one end of each pole. From opposite corner, flex pole and insert tip into grommet.



Grommet Pole Attachment



Center Double Clip



Guy Out with Storage Pocket



Rain Fly Grommet Attachment



Step 3: Attach center clips over both poles at center "X". Work around the tent attaching all clips to the poles.



Guy out pole attachment hook & loop loop (underside of fly)



Step 4: Drape rain fly over tent body. Attach hook & loop on underside of fly to poles (at guy out). Attach grommet on rain fly corner webbing to pole tip at stake loops. Stake out tent vestibules and guy out as needed.

Visit [Kelty.com](http://Kelty.com) for details regarding exclusive Field-Repairable-Zipper.