

ROVER



In order to familiarize yourself with your new tent, we recommend you "test pitch" before your first camping trip. For additional information please visit www.kelty.com.

Package Includes: Rover tent body, two poles, carry bag, guylines, and tent stakes.

1



Find an even piece of ground clear of sticks and rocks. Lay out tent and stake corners. Assemble poles. Lay taller twin poles at front and short single pole at back of tent.

2



Insert back pole into grommets at top and bottom of back wall. Stand up and stake out guyline to secure.

3



Stand up front pole with tips in stake loop grommets. Lift tent by webbing through V in poles and stake out cord.

4



Attach pole clips and tighten front guyline cord to achieve tight set up.