


SALIDA 2,4



In order to familiarize yourself with your new tent, we recommend you “test pitch” before your first camping trip. For additional information please visit www.kelty.com.

Package Includes: Tent carry bag, tent body, tent fly, two poles, guyline cords, and tent stakes.

1



On an even piece of ground lay out tent body and stake corners. Assemble poles, making sure all pole sections are fully connected at joints. Lay poles on top of tent body in an X pattern.

2



Insert pole tip into grommets at back stake loop corners, flex pole to stand up and insert pole tip into grommets on front stake loops. Attach center clip over pole near crossing point of poles.



Grommet Pole Attachment



Pole Clip



Hook & loop fly pole wrap



Fly Attachment

3



Work your way around the tent to attach all clips to poles.

4



Drape tent fly over tent body. Attach hook & loop on underside of fly (at guy out points) to poles. Attach fly buckle to tent buckle at each stake loop. Stake out vestibule and guylines.