

# SEQUOIA 4, 6



Sequoia 4 pictured

In order to familiarize yourself with your new tent, we recommend you “test pitch” before your first camping trip. For additional information please visit [www.kelty.com](http://www.kelty.com).

Package Includes: Tent carry bag, tent body, tent fly, two main pole lines, ridge pole line, guy line cord, and tent stakes.

1



On an even piece of ground lay out tent body and stake corners. Assemble poles, making sure all pole sections are fully connected at joints. Slide main (long) poles through the pole sleeves that cross in the middle, the short poles & parallel pole sleeves will be used in step 3.

2



Insert pole tips into the grommets at back corners, flex pole to stand up and insert pole tips into grommets at front corners. Be sure to lift tent body as well as pole.




Grommet Pole Attachment & Fly attachment



Hook & Loop pole connectors (located under guy out points)



Kelty Connect ridge pole connector.



Ridge pole connector & rain fly attachment.

3



Work your way around the tent to attach all clips to poles. Slide ridge pole through pole sleeve above door, and attach Kelty Connect ridge pole connector on each side.

4



Lay tent fly over tent matching colored webbing on tent fly to webbing stake loop on tent body. Using the “Ridge pole connector & rain fly attachment” as image above connect fly to ridge poles. Attach guy out hook & loop pole wrap on underside of fly to poles (x4). Connect rain fly to each stake out corner with side release buckle. Stake out vestibule doors and guy lines.